KitchenAid® CONTROL PANEL PARTS

OVER THE RANGE MICROWAVE

For Model: KHMS105BBL2, KHMS105BWH2, KHMS105BAL2
(Black) (White) (Almond)



Illus. No.	Part No.	DESCRIPTION
1		Controller Sub Assy.
	4358890	Black Model
	4358891	White Model
	4358819	Almond Model
2		Control Panel
	4358818	Black Model
	4358542	White Model
	4358543	Almond Model
3	4358821	Bracket, Control
4		Key Membrane
	4358545	Black Model
	4358817	White Model
	4358547	Almond Model
5	4358550	PCB Sub Assy.
6		Screw
	4358762	Black Model
	4358381	White & Almond
7	4358192	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR PARTS

For Model: KHMS105BBL2, KHMS105BWH2, KHMS105BAL2
(Black) (White) (Almond)



Illus. No.	Part No.	DESCRIPTION
1		Door Assembly
	4358556	Black Model
	4358559	White Model
	4358560	Almond Model
2	4358750	Frame Door
3	4358752	Tape, Seal
4	4358546	Latch
5	4358607	Spring, Latch
6	4358820	Plate, Hinge
7		Panel, Door
	4358563	Black Model
	4358565	White Model
	4358568	Almond Model
8		Baffle, Door
	4358569	Black Model
	4358570	White Model
	4358572	Almond Model
9		Glass, Door
	4358574	Black Model
	4358575	White Model
	4358591	Almond Model
10		Deco Door
	4358716	Black Model
	4358721	White Model
	4358714	Almond Model
11	4358558	Choke Cover
12	4358067	Screw
13	4358192	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Model: KHMS105BBL2, KHMS105BWH2, KHMS105BAL2
(Black) (White) (Almond)



Illus. No.	Part No.	DESCRIPTION
1		Outer Case
	4358926	Black Model
	4358925	White Model
	4358927	Almond Model
2	4358928	Mounting Bracket
3		Grille Vent
	4358757	Black Model
	4358814	White Model
	4358815	Almond Model
4	4358759	Bracket Front
5	4358760	Power Cord
6	4358761	Cover, Power Cord
7	4358383	Holder, Shelf
8	4358816	Bracket, Grille
9	4358762	Screw
10	4358489	Screw
11	4358192	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MAGNETRON AND AIR FLOW PARTS

For Model: KHMS105BBL2, KHMS105BWH2, KHMS105BAL2
(Black) (White) (Almond)



Illus. No.	Part No.	DESCRIPTION
1	4358059	Magnetron
2	4358772	Thermostat
3	4358774	Transformer
4	4158947	Capacitor
5	4358775	Thermostat
6	4358777	Motor
7	4358778	Bracket
8	4158827	H.V. Cable
9	4158923	H.V. Diodle−Cable
10	4358823	Lead Wire
11	4358780	Lead Wire
12	4358781	Plate, Bottom
13	4358782	Stirrer Fan Disk
14	4358783	Holder Disk
15	4158731	Ceramic Plate
16	4158213	Washer
17	4358489	Screw
18	4358192	Screw
19	4358376	Screw
20	4158747	Screw
21	4358188	Screw
22	4158212	Nut
23	4158371	Probe

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INTERIOR PARTS

For Model: KHMS105BBL2, KHMS105BWH2, KHMS105BAL2
(Black) (White) (Almond)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INTERIOR PARTS

For Model: KHMS105BBL2, KHMS105BWH2, KHMS105BAL2
(Black) (White) (Almond)

Illus. No.	Part No.	DESCRIPTION
1	4358784	Motor, Fan
2	4358564	Guide Suction
3	4358379	Blower Fan
4	4358785	Fuse Holder
5	4358704	Fuse
6	4358055	Push Nut
7	4358786	Air Duct
8	4358787	Motor, Ventilation
9	4358789	Cover, Lamp
10	4358790	Lamp, Holder
11	4158344	Oven Lamp
12	4158376	Motor Condenser
13	4358536	Guide Air
14	4158368	Base Thermostat
15	4358791	Cover, Connector
16	4358792	Filter
17	4358793	Lead Wire
18	4358192	Screw
19	4358190	Screw
20	4358376	Screw
21	4358191	Screw
22	4358015	Screw
23	4358064	Screw
24	4358826	Sensor Box
25	4358825	Sensor
26	4358833	Rack

OPTIONAL PARTS (NOT INCLUDED)

Illus. No.	Part No.	DESCRIPTION

Following Parts Not Illustrated

LITERATURE PARTS

LIT4358595	Guide, Use & Care
LIT4358932	Instructions, Installation
LIT4358516	Tech Sheet
LIT4358805	Cookbook

LATCH BOARD PARTS

For Model: KHMS105BBL2, KHMS105BWH2, KHMS105BAL2
(Black) (White) (Almond)



Illus. No.	Part No.	DESCRIPTION
1	4358794	Board, Latch
2	4158940	Micro Switch
3	4358269	Micro Switch
4	4158941	Micro Switch
5	4358267	Micro Switch
6	4358795	Lever Monitor
7	4358271	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

VENTILATION PARTS

For Model: KHMS105BBL2, KHMS105BWH2, KHMS105BAL2
(Black) (White) (Almond)



Illus. No.	Part No.	DESCRIPTION
1		Base Plate
	4358930	Black Model
	4358929	White Model
	4358931	Almond Model
2		Cover Cooktop Glass
	4358765	Black Model
	4358533	White & Almond Model

Illus. No.	Part No.	DESCRIPTION
3	4358571	Glass, Cooktop Lamp
4	4358767	Cushion−Glass
5	4358768	Lead Wire Assy.
6	4358769	Cover, Wire
7	4158344	Oven, Lamp

Illus. No.	Part No.	DESCRIPTION
8	4358853	Air Filter
9	4358790	Lamp Holder
10	4358380	Screw
11	4358190	Screw

INSTALLATION PARTS

For Model: KHMS105BBL2, KHMS105BWH2, KHMS105BAL2
(Black) (White) (Almond)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INSTALLATION PARTS

For Model: KHMS105BBL2, KHMS105BWH2, KHMS105BAL2
(Black) (White) (Almond)

Illus. No.	Part No.	DESCRIPTION
1	4158541	Exhaust Adapter
2	4158319	Exhaust Damper
3	4158321	Toggle Bolt/Wings
4	4158326	Toggle Wing
5	4158323	Screw
6	4158315	Screw
7	4158314	Washer
8	4358924	Plate, Mounting Wing
9	4358011	Clamp
10	4358012	Bushing
11	4358934	Sheet−Top Cabinet Template
12	4358935	Sheet−Wall Template
13	4358188	Screw
14	4358192	Screw
15	4358010	Screw
16	4358933	Safety Rod